


HMMWV...

PROPER LUBE HELPS STEERING WHEEL MOVE



Using your HMMWV's steering wheel is pretty simple. All you have to do is turn it in the direction you want to go. But if you don't properly lube the intermediate steering shaft, that could be a problem.

Without lube, the steering shaft will bind. Then those simple left and right turns won't be so easy. And that means trouble when you're driving towards a curve in the road!

Keep the steering wheel turning by lubing the intermediate steering shaft with GAA semiannually or every 3,000 miles, whichever comes first.

And don't forget that the shaft has **three** lube points. The one on the shaft and the one on the top knuckle of the U-joint usually get lubed. And one that often gets missed is on the lower knuckle, which is blocked from above by the alternator.

